

DOSING PUMPS

TJ-MD SERIES

TOSHCON JESCO (INDIA) PVT. LTD., offers solenoid operated electronic diaphragm type Dosing Pumps.



TJ-MD 8/ 12

The magnetic dosing pumps are glandless diaphragm pumps with electromagnetic drive. The prime benefit of magnetic drive is the excellent proportional controllability.

The magnetic dosing pumps are manufactured according to modern production methods using high quality materials. Selected high quality components are used in the controls to ensure a high degree of reliability. The Pumps are maintenance and service free when it is properly installed and suitably operated.



TJ-MD 20/ 40/ 100

SALIENT FEATURES :

- * Separation Chamber
- * Changeover function to external control by 0/4...20 mA standard signal
- * Connection for level control with alarm signaling
- * Stroke Length settable from 0...100%
- * Stroke Frequency settable from 0...100%/min
- * Double Ball Valves for better accuracy

Model	TJ - MD	8	12	20	40	100
Maximum Pressure (Bar)		10	4	10	4	1.5
Litre / Hr.	At max. Pressure	6	12	15.5	46	90
Stroke/min		100	100	70	70	70
ml / Stroke		1	2	4.3	12.8	25
Power (W)		30	30	70	70	70
Approx. weight (kg)		5	5	10	14	14
MOC of wetted pumps		Standard : PP		Optional : PVC / SS / TEFLON		

Please call us for more details on Dosing Pumps and our other products viz. Chemical Dosing System, Gas Chlorinators, Chlorination System, Safety equipments etc. at:

Mobile: +91-9351497757

Email: metering@toshcon.com

TOSHCON JESCO (INDIA) PVT. LTD.,

Kutchery Road, Ajmer - 305001 (Raj.) INDIA

CIN: U33129MH1993PTC070667

Ph.: +91-145-2420507 E-mail: info@toshcon.com Website: www.toshcon.com

REGD OFFICE: 401, Manish Chamber, Sonawala Cross Lane, Goregaon (E), MUMBAI - 63